

Manual, Assembly instruction: Brodit 102808

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the holder.

1. For mounting on 10" ModTek Hard Case. Remove two screws from the long side of the Hard Case. Take the D-ring, screw and washer. Place the washer on the screw, then insert the screw through the D-ring and screw it into the Hard Case. Repeat on the opposite side. **2.** Fully assembled. The shoulder strap is correctly mounted on the long side of the Hard Case. Adjust the strap length as needed. **3.** For mounting on 8" ModTek Hard Case. Remove two screws from the short side of the Hard Case. Take the D-ring, screw and washer. Place the washer on the screw, then insert the screw through the D-ring and screw it into the Hard Case. Repeat on the opposite side. **4.** Fully assembled. The shoulder strap is correctly mounted on the short side of the Hard Case. Adjust the strap length as needed.