

Manual, Assembly instruction: Brodit 213402

Taxameter Extra strength mounting platform for taxameter.

1.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip.
2. Press the curved edge on the upper part of the ProClip into the gap between the air vent and the dashboard.
3. Flip the ProClip downward so the upper curved edge hooks under the air vent. Press the grooved edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the dashboard. Press until you hear + feel it snaps into place.
4. The ProClip is in place.