

Manual, Assembly instruction: Brodit 213437

Extra Stark Monteringsplattform, Center mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin ends of the enclosed gap openers into the gap between the air vent and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the upper part of the ProClip into the gap between the gap openers. Flip the ProClip downward so the curved edge hooks under the air vent. Pull out the gap openers.

2. Press the gap openers into the gap between the frame surrounding the air vent and the dashboard. Pull the ProClip toward you, press downward and hook the lower edge into the gap between the gap openers.

3. Press forward on the lower part of the ProClip and downward on top of the ProClip so it goes into place properly. Pull out the gap openers.

4. The ProClip is in place.