

Manual, Assembly instruction: Brodit 213443

Extra strength mounting platform.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing.

1. Peel off the adhesive tape covers on the mount. Press the angled edge on the upper part of the mount into the gap between the air vent and the dashboard, by the windshield.

2. Pull the mount toward you and hook the angled edge on the lower part into the gap between the center console and the dashboard.

3. Press forward on the lower part of the mount so the angled edge goes all the way into the gap.

4. The mount is in place.