

Manual, Assembly instruction: Brodit 213455

Left mount, High

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the thin end of the enclosed gap opener into the gap between the A-post and the rubber sealant so you can pull out the rubber sealant slightly. Pull out the gap opener.

2. Press the curved edge on the lower part of the ProClip into the gap. Hook the curved edge on the ProClip around the A-post.

3. Press the ProClip forward/toward the A-post so the angled edge hooks around the A-post by the windscreen. Press the ProClip toward the A-post so the adhesive tapes attach.

4. The ProClip is in place.