

Manual, Assembly instruction: Brodit 213457

Extra strength mounting platform.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the frame surrounding the coin compartment and the dashboard. Press forward on the lower part of the ProClip so the angled edge goes all the way into the gap.

2. Hook the angled edge on the upper part of the ProClip into the gap between the frame surrounding the air vents and the frame surrounding the coin compartment. Press down on top of the ProClip so the angled edge goes all the way into the gap.

3. Press the ProClip toward the dashboard so the adhesive tapes attach.

4. The ProClip is in place.