

Manual, Assembly instruction: Brodit 213461

Center mount, Extra strength mounting platform. ONLY for vehicles with double DIN stereo.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the control panel and the frame surrounding the display.

2. Press upward on the dashboard overhang and in the same time press forward on the upper part of the ProClip so the upper edge goes into the gap under the dashboard overhang.

3. The ProClip is in place.

4. The ProClip is in place.