

Manual, Assembly instruction: Brodit 213462

Center mount, Extra strength mounting platform.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of one of the enclosed gap openers into the gap between the upper and lower section of the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the lower part of the ProClip into the gap next to the gap opener.

2. Flip the ProClip upward/forward so the curved lower edge hooks behind the lower section of the dashboard. Pull out the gap opener.

3. Press both gap openers into the gap between the speaker vent and the dashboard. Press forward on the ProClip and hook the angled edge into the gap between the gap openers. Press the angled edge all the way into the gap. Pull out the gap openers.

4. The ProClip is in place.