

Manual, Assembly instruction: Brodit 213469

Center mount, Extra strength mounting platform.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the control panel and the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip. Press the curved edge on the lower part of the ProClip into the gap next to the gap opener.

2. Press firmly forward on the lower part of the ProClip so the curved edge goes all the way into the gap. Hold the ProClip in that position and flip the upper part upward/forward so the curved lower edge hooks behind the dashboard. Pull out the gap opener.

3. Press the gap opener into the gap between the frame surrounding the control panel and the compartment. Press the upper part of the ProClip forward so the angled edge hooks into the gap next to the gap opener. Press down on top of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.