

Manual, Assembly instruction: Brodit 213471

Center mount, Extra strength mounting platform



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Hook the two angled upper parts of the ProClip into the gap between the frame surrounding the air vent and the dashboard. Press downward on top of the upper parts so all of the angled edges go all the way into the gap.

2. Hook the angled edge on the lower part of the ProClip under the dashboard overhang. Hold the two upper parts in the gap and in the same time press forward on the face plate so the ProClip contracts and is firmly in place.

3. Tighten gently the large nuts on top of the ProClip so the ProClip contracts and is firmly in place. Use an Allen key to tighten the small nuts and lock the ProClip into the desired position.

4. The ProClip is in place.