

Manual, Assembly instruction: Brodit 213476

Center mount, Extra strength mounting platform.



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip can be mounted along the whole width of the panel.

1. Press the angled top part of the ProClip into the gap between the dash board and the wind shield.
2. Bend the bottom part of the ProClip outward/forward at the same time pull it downward.
3. Hook the bottom part of the ProClip around the edge of the frame surrounding the control panel.
4. The ProClip is in place.