

Manual, Assembly instruction: Brodit 213514

Center mount, High

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the product.

1. Use the enclosed alcohol pad to clean the area where the mount is to be installed. Press the thin end of the enclosed gap openers into the gap between the frame surrounding the control panel and the dashboard, to widen the gap. Peel off the adhesive tape covers on the mount.

2. Press the angled edge on the lower part of the mount into the gap between the gap openers. Press downward on the lower part of the mount so the angled edge goes all the way into the gap. Pull out the gap opener.

3. Press the gap openers into the gap between the frame surrounding the air vent and the dashboard. Hook the angled edge on the upper part of the mount into the gap between the gap openers. Press downward on top of the mount so the angled edge goes all the way into the gap. Pull out the gap openers.

4. The mount is in place.