

Manual, Assembly instruction: Brodit 213521

Center mount, Extra strength mounting platform.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape cover on the ProClip. Insert the angled upper edge of the ProClip into the gap between the paneling surrounding the air vents and the panel in front of the information display.
2. Move the ProClip downward so the angled upper edge hooks behind the paneling.
3. Press the downward on top of the ProClip so the lower edge can hook around the edge of the paneling surrounding the air vents.
4. The ProClip is in place.