

Manual, Assembly instruction: Brodit 213525

Extra strength mounting platform. Center mount.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Hold the ProClip in position where it is to be installed. Place the enclosed gap opener directly to the left of the upper edge of the ProClip and press the thin end into the gap on top of the dashboard, to widen the gap.

2. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener. Press/Flip the ProClip downward so the angled upper edge hooks under the front section of the dashboard. Pull out the gap opener. Hook the angled edge on the ProClip under the dashboard overhang. Press the upper edge on the ProClip downward into the gap, in the same time press forward on the ProClip face plate so the ProClip contracts.

3. Tighten the large nut on top of the ProClip so the ProClip contracts and is firmly in place. Use an enclosed Allen key to tighten the small nut and lock the nut.

4. The ProClip is in place.