

Manual, Assembly instruction: Brodit 213532

Extra strength mounting platform

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the mount.

1. Open the glove compartment. Use the enclosed alcohol pad to clean the area where the mount is to be installed. Press the thin end of the enclosed gap opener into the gap between the glove compartment and the dashboard, to widen the gap. Peel off the adhesive tape cover on the mount. Hook the angled edge on the upper part of the mount over the dashboard edge.

2. Press downward on the mount so the angled lower edge hooks into the gap next to the gap opener. Pull out the gap opener.

3. Press upward on the lower part of the mount so the angled edge goes all the way into the gap and the adhesive tape attaches. Close the glove compartment.

4. The mount is in place.