

## Manual, Assembly instruction: Brodit 213538

Center mount Extra strong mounting platform.

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the angled edge on the lower part of the ProClip into the gap between the frame surrounding the air vent panel and the lower dashboard section.
2. Pull the upper part of the ProClip upward and hook the grooved edge over the frame surrounding the air vent panel.
3. Press on the ProClip so the adhesive tapes attach.
4. The ProClip is in place.