

Manual, Assembly instruction: Brodit 213542

Center mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the upper part of the ProClip into the gap between the dashboard top and dashboard trim panel.

2. Press/flip the lower part of the ProClip downward/forward so the angled upper edge hooks under the dashboard top. Press the lower part of the ProClip forward so the lower edge snaps into place behind the dashboard trim panel.

3. This ProClip can be placed anywhere within the width of the upper control panel.

4. The ProClip is in place.