

Manual, Assembly instruction: Brodit 213543

Center mount, Extra strength mounting platform

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap.

2. Hook the angled upper part of the ProClip into the gap next to the gap opener. Remove the gap opener. Press downward on top of the ProClip so the angled edge goes all the way into the gap.

3. Hook the angled edge on the lower part of the ProClip between the dashboard overhang and the frame surrounding the display. Hold the upper parts in the gap and in the same time press forward on the face plate so the ProClip contracts and is firmly in place. Tighten the large nut gently on top of the ProClip so the ProClip contracts and is firmly in place. Use an Allen key to tighten the small nut and lock the ProClip into the desired position.

4. The ProClip is in place.