

Manual, Assembly instruction: Brodit 213546

Center mount, High strength mountingplatform


1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Place the ProClip face plate centered above the display so the tab behind of the face plate rests on top of the dashboard.

2. Press forward on the ProClip and hook the J-shaped edge on the ProClip over the edge of the dashboard by the air vent, closest to the windshield.

3. The ProClip is in place.

4. The ProClip is in place.