

Manual, Assembly instruction: Brodit 213548

Center mount, High. High strength mounting platform.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Remove the panel on top of the dashboard. Use the included gap opener if needed.
2. Place the ProClip dash plate into the location where the original plate was. Press/Slide the screw tabs outward to hook the tabs under the dashboard frame. Tighten the screws to secure the ProClip panel onto the dashboard.
3. Secure the pedestal mount with the included machine screws.
4. The ProClip is in place, with device holder in place (not included).