

Manual, Assembly instruction: Brodit 213550

Center mount, High strength mounting platform



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the dashboard and the speaker vent, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of the adhesive tape on the ProClip. Hook the angled edge on the upper part of the ProClip into the gap next to the gap opener. Press the lower part of the ProClip downward so the angled upper edge of the ProClip hooks under the speaker vent. Pull out the gap opener.

2. Hook the angled edge on the lower part of the ProClip under the dashboard overhang. Hold the upper part in the gap and in the same time press forward on the face plate so the ProClip contracts and is firmly in place.

3. Tighten the large nut gently on top of the ProClip so the ProClip contracts and is firmly in place. Use an Allen key to tighten the small nut and lock the ProClip into the desired position.

4. The ProClip is in place.