

Manual, Assembly instruction: Brodit 213551

Extra strenght mounting platform.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip consist of two parts: Part 1. ProClip attaching part (plastic) Part 2. Pedestal Mount (metal)

1. Remove the rubber pad at the bottom of the shallow pocket in the top center of the dash. Remove the two screws from the bottom of the pocket. A Torx head screw driver might be needed for the screws being removed.

2. Align the holes in the bottom of Part 1 with the threaded holes where you removed the dash screws. 2009 - 2012 models use outside holes. 2012 - 2018 models use inside holes. Insert the included screws through the holes in Part 1 and tighten the screws into the threaded holes in the bottom of the dash pocket.

3. Attach Part 2 on Part 1 with the included machine screws.

4. The ProClip is in place.