

Manual, Assembly instruction: Brodit 213557

Extra strength mounting platform

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Remove the rubber pad at the bottom of the shallow pocket on top of the dashboard.
2. Remove the two screws from the bottom of the pocket. Place the ProClip in the pocket so the holes match the threaded holes where you removed the dash screws. Insert the screws through the holes in the ProClip and secure the mount by tightening the screws into the threaded holes in the bottom of the dash pocket.
3. Attach the pedestal mount to the ProClip with the included machine screws.
4. The ProClip is in place.