

Manual, Assembly instruction: Brodit 213558

Center mount, Extra strength mounting platform.



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the angled edge on the lower part of the ProClip into the gap between the frame surrounding the air vent and the dashboard.

2. Hook the angled edge on the upper part of the ProClip under the top part of the dashboard.

3. Hold the upper part in the gap and in the same time press forward on the face plate so the ProClip contracts and is firmly in place. Tighten the large nut gently on top of the ProClip so the ProClip contracts and is firmly in place. Use an Allen key to tighten the small nut and lock the ProClip into the desired position.

4. The ProClip is in place.