

Manual, Assembly instruction: Brodit 213560

Center mount This mount will block the compartment on top of the dashboard on Karoq.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing.

1. Karoq: Hook the angled edges on the upper parts of the mount into the gap between the compartment and the dashboard. Hook the angled edges on the lower oart of the mount under the dashboard overhang. **2.** Kodiak: Hook the angled edges on the upper parts of the mount over the frame surrounding the speaker vent. Hook the angled edges on the lower oart of the mount under the dashboard overhang.

3. Hold the upper parts into place, at the same time press forward on the face plate so the parts are drawn together and the mount is firmly in place. Lock the mount into place by carefully tightening the lock screws alternately. It is important not to tighten the screws too hard. When the mount is firmly in place, lock the position with an Allen key.

4. The mount is in place.