

Manual, Assembly instruction: Brodit 213561

Center mount, Extra strength mounting platform.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin edge of the enclosed gap opener into the gap on top of the dashboard, to widen the gap. Peel off the adhesive tape covers on the ProClip.
2. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener.
3. Press down on the face plate of the ProClip and hook the lower edge into the gap between the center console frame and the frame surrounding the display. Pull out the gap opener.
4. The ProClip is in place.