

Manual, Assembly instruction: Brodit 213562

Center mount, High strength mounting platform.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin edge of the enclosed gap openers into the gap between the frame surrounding the tray and the dashboard, to widen the gap. Peel off the adhesive tape cover on the ProClip.

2. Press the thin lower edge of the ProClip into the seam between the panel around the radio and the padded dashboard. Press forward on the ProClip and hook the upper edge into the gap between the gap openers.

3. Press down on top of the ProClip so the upper edge goes all the way into the gap. Pull out the gap openers.

4. The ProClip is in place. This ProClip can be placed anywhere within the width of the tray.