

Manual, Assembly instruction: Brodit 213567

Center mount. Extra strength mounting platform.



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap between the dashboard overhang and the panel surrounding the instrument panel, to widen the gap. Press the lower edge of the ProClip into the gap next to the gap opener. Pull out the gap opener.

2. Press the gap opener into the gap between the dashboard and the compartment. Press forward on the ProClip and hook the upper edge into the gap next to the gap opener. Pull out the gap opener.

3. Peel off the adhesive tape covers on the mounting plate. Place the mounting plate onto the ProClip so it is properly in place and the adhesive tape attaches to the dashboard. Attach the mounting plate with the enclosed screws.

3. The ProClip is in place.

4. The ProClip is in place.