

Manual, Assembly instruction: Brodit 213570

Center mount With hinge feature. Easy access to both display and installed device.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip.
2. Press the sides out slightly on the ProClip. Place the ProClip over the screen and press down on the ProClip until the angled part of the ProClip stops against the screen.
3. Squeeze the sides against the screen.
4. The ProClip is in place.