

Manual, Assembly instruction: Brodit 213572

Center mount, High strength mounting platform ONLY for models with display.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip first: any holder & equipment is to be attached after the ProClip is in place.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the angled edge on the lower part of the ProClip into the gap under the dashboard.

2. Pull up the rubber mat in the compartment slightly.

3. Press forward on the upper part of the ProClip so the angled edge hooks/snaps into place over the dashboard edge surrounding the compartment.

4. The ProClip is in place.