

Manual, Assembly instruction: Brodit 213576

Center mount, High strength mounting platform. NOT for models with upper glove compartment.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. This ProClip can also be placed by the right air vent.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap openers into the gap above the dashboard, to widen the gap between the dashboard and the compartment. Peel off the cover of the adhesive tape on the ProClip. Hook the angled edge on the lower part of the ProClip under the frame surrounding the air vent.

2. Press the upper part of the ProClip forward so the curved edge hooks into the gap next to the gap openers.

3. Press the upper edge of the ProClip all the way into the gap. Pull out the gap openers.

4. The ProClip is in place.