

Manual, Assembly instruction: Brodit 213586

Center mount, Extra strength mounting platform

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder + equipment is to be attached after the mount is in place.

1. Place the front and back sections of the mount together as shown. Place the gear inside the channel. Turn the mount over. Fit the tension nut into the gear recess. Hand tighten the set screw through the tension nut.
2. Hook the back lip on the back edge of the accessory tray panel. Hook the front lip over the front edge of the dim recess on the face dashboard panel. Press the front and back of the mount together.
3. Add tension to the mount by turning the tension nut counterclockwise with a 13 mm or adjustable crescent wrench. Secure the nut by tightening the set screw using the included hex wrench.
4. The mount may be installed as left or right as desired above the radio dim. The ProClip mount is in place.