

Manual, Assembly instruction: Brodit 215588

Tilt swivel mount. Ball Size is 16 mm In Diameter.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the mount. Please Note that the original TomTom Dock is not included.

1. Place the tilt swivel mount in the desired position. Screw the mount into place with the enclosed screws.

2. The tilt swivel mount is in place. This mount fits a number a devices, the installation procedure may vary but the principal is similar for all devices.

3. For the installation, you will use the original mount that comes with the GPS and press it onto the tilt swivel mount. Place the original mount by the tilt swivel mount so the tilt swivel fits. Press the original mount onto the tilt swivel mount, press until you feel it is properly in place.

4. The mount is in place.