

Manual, Assembly instruction: Brodit 216262

For attachment on Still Clamp mount 0711707/0711708 (not included). Radial AMPS holes. Made of metal.



Please read all of the instructions and look at the pictures before attaching the mount.

1. Make sure that the till Clamp mount 0711707/071170 (not included) is properly in place and placed in a suitable position for your installation.
2. Place the mount onto the Clamp mount so the holes match. Attach the mount with the enclosed screws.
3. Adjust the angle of the face plate. Tighten the screws so the mount is firmly in place.
4. The mount is in place.