

Manual, Assembly instruction: Brodit 216275

Vibration dampeners, Shore A 60 Hardness. For installations weighing up to 2000g. With AMPS, Vesa 75 holes.

1.)



2.)



3.)



4.)



Read all of the instructions and look at the pictures before the installation.

1. Mount the Vibration dampener: Place the Vibration dampener onto the desired position. Screw the Vibration dampener into place, for mounting surface ? 3mm thick use the short screw.

2. Mount the Vibration dampener onto a holder without tilt swivel: Place the holder onto the desired position and screw into place, for mounting surface ? 3mm thick use the short screw.

3. The holder is in place.

4. The Vibration dampener is in place.