

Manual, Assembly instruction: Brodit 216499

Retention-lock module for Module Upgrade holders without Rugged Boot / Exoskeleton, Zebra original expansion back.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the holder.

1. Place the locking block on the back of the holder so that the screws fit in the holes.
2. Screw on the locking block with the enclosed screws.
3. To place the device in the holder: Slide the device sideways carefully into the holder. Push the lock block downward. To remove the device from the holder: Slide the lock block upward.
4. The holder is in place.