

Manual, Assembly instruction: Brodit 216500

Key lock module, 2 keys included, for Module Upgrade holders without Rugged Boot / Exoskeleton, Zebra original expansion back.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the holder.

1. Place the locking block on the back of the holder so that the screws fit in the holes.

2. Screw on the locking block with the enclosed screws.

3. Slide the device sideways carefully into the holder. Press the lock sideways onto the left part of the holder. Press the button to lock. Use the enclosed key to open the lock. Remove the lock by sliding it sideways away from the holder. Slide the device sideways out of the holder.

4. The holder is in place.