

Manual, Assembly instruction: Brodit 217035

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the product.

1. Loosen the screws in the printer.

2. Place the mount on the printer so that the holes match. Use the two long screws for the two bottom holes, two short screws for the top holes.

3. Place the Pm mount so that the holes on the printer bracket line up. Secure with the included screws.

4. The product is in place.