

Manual, Assembly instruction: Brodit 217059

Universal scanner holder.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the mount.

1. Attach the mount: Place the mount into the desired position and attach it with the enclosed screws.
2. Put the device in place: Hold the device above the mount. Slide/press it straight into the mount so it is properly held in place. Remove the device: Pull the device straight out from the mount.
3. The mount is in place.
4. The mount is in place.