

Manual, Assembly instruction: Brodit 217266

V-slot button and clip holder. With predrilled

AMPS holes M4.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the holder.

1. Place the mount onto the desired position and screw into place with the enclosed screws.
2. Place the device in the mount.
3. The mount is in place.
4. The mount is in place with the device.