

Manual, Assembly instruction: Brodit 604136

Right mount, High

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Press the thin end of the enclosed gap opener into the gap between the A-post panel frame and the rubber sealant. Pull/flip the rubber sealant open. Pull out the gap opener.

2. Insert the angled edge on the lower part of the ProClip into the gap under the rubber sealant and hook it behind the A-post panel edge.

3. Press firmly upwards and rightward on the ProClip so the upper angled edge snaps around the A-post panel edge. Press down on top of the ProClip so the angled edge goes all the way into the gap.

4. The ProClip is in place.