

Manual, Assembly instruction: Brodit 604172

Right mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Pull out the rubber sealant by the A-post slightly. Hook the angled edge on the lower part of the ProClip behind the A-post, under the rubber sealant.
2. Press upward/rightward on the ProClip so the angled upper edge hooks around the A-post by the windshield. Press until you hear/feel it snaps into place.
3. Slide the ProClip downward.
4. The ProClip is in place.