

Manual, Assembly instruction: Brodit 604262

Right mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Clean the area where the ProClip is to be installed with the enclosed alcohol pad. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the lower part of the ProClip into the air vent and hook it over the lower edge of the air vent.
2. Press the upper part of the ProClip downward and forward so the upper edge hooks under the upper edge of the air vent.
3. Press forward on the ProClip so the adhesive tapes attach.
4. The ProClip is in place.