

Manual, Assembly instruction: Brodit 604999

Right mount, High



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Pull out the rubber sealent on the A-post slightly. Remove the adhesive tape cover on the ProClip.
2. Press the angled edge on the lower part of the ProClip into the gap and hook it around the A-post.
3. Press the ProClip upward/forward so the angled upper edge hooks around the A-post.
4. The ProClip is in place.