

Manual, Assembly instruction: Brodit 605070

Right mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Hook the angled lower edge of the ProClip around the dashboard overhang above the light control knob.
2. Push the ProClip upward, making sure the adhesive tape fastens properly.
3. Press the ProClip upward/forward. Press the angled upper edge of the ProClip into the gap on the lower inside of the air vent.
4. The ProClip is in place.