

Manual, Assembly instruction: Brodit 605208

Right mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before installing the ProClip.

1. Insert the thin end of the enclosed Gap Opener (Spaltöffner) into the lower right side of the gap between the panel surrounding the air vent and the remainder of the dash, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Remove the adhesive tape covers on the ProClip. Insert the lower angled edge of the ProClip into the gap next to the Gap Opener (Spaltöffner). Remove the Gap Opener (Spaltöffner).

2. Insert the thin end of the enclosed Gap Opener (Spaltöffner) into the upper right side of the gap between the panel surrounding the air vent and the remainder of the dash, to widen the gap. Insert the upper angled edge of the ProClip into the gap next to the Gap Opener (Spaltöffner). Remove the Gap Opener (Spaltöffner).

3. Press onto the ProClip to make sure the adhesive tape fastens as good as possible.

4. The ProClip is in place.