

Manual, Assembly instruction: Brodit 605274

Right mount

1.)



2.)



3.)



4.)



Please read the instructions and look at the pictures before installing the ProClip.

1. Pull out the rubber sealant on the A-post slightly.
2. Press the angled edge on the lower part of the ProClip into the gap.
3. Press the ProClip forward so the angled upper edge hooks into the gap between the windshield and the A-post.
4. The ProClip is in place.