

Manual, Assembly instruction: Brodit 605298

Right mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Pull out the rubber sealant slightly on the A-post.

2. Hook the rounded edge on the right part of the ProClip around the A-post.

3. Press the left part of the ProClip upward/forward so the angled edge hooks around the A-post. Press downward on the left part ProClip so the angled edge goes all the way into the gap.

4. The ProClip is in place.