

Manual, Assembly instruction: Brodit 605495

Right mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Press the right edge of the ProClip into the gap between the frame surrounding the air vent and the dashboard.

2. Hook the left edge of the ProClip into the gap between the frame surrounding the air vent and the dashboard.

3. Press the edges of the ProClip toward the frame surrounding the air vent, on both sides at the same time, so the edges go all the way into the gaps and the adhesive tapes attach properly.

4. The ProClip is in place.