

Manual, Assembly instruction: Brodit 605589

Right mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the grooved lower edge over the frame surrounding the air vent.

2. Press the ProClip forward and hook the grooved upper edge under the frame surrounding the air vent.

3. The ProClip is in place.

4. The ProClip is in place.